

DH 44 / DH 62




Fig. 1

Pos DH44	Pos DH62	Code	Description	Pos DH44	Pos DH62	Code	Description
1	1	4140.201	PC Board	-	18	4140.266	Compressor Starting Group
2	2	4140.245	Dehumidostat	19	-	4140.254	Refrigerant Filter With Capillary
3	3	4140.204	Dehumidostat Knob	-	19	4140.267	Refrigerant Filter With Capillary
4	4	4140.205	Control Panel With Cap	20	20	4140.255	Tank
5	5	4140.206	Support Pcb	21	21	4140.256	Spring
6	6	S/R	Right Panel	23	23	4140.226	Power Cord
7	7	S/R	Left Panel	24	24	4140.258	Microswitch
8.1	8.1	S/R	Top Cover	25	25	4140.259	Air Filter
8.2	8.2	S/R	Inside Grille	26	26	4140.260	Filter Holder
8.3	8.3	S/R	Outside Grille	28	28	4140.230	Thermostat With Hot Gas
8.4	8.4	S/R	Lower Front Panel	29	29	4140.261	Solenoid Valve
9	9	4140.246	Evaporator	30	30	4140.262	Handle
10	10	4140.202	Lower Condensate Collecting Tray	31	31	4140.158	Hours Counter
11	11	4140.247	Top Tray	33	33	S/R	Pipe Handle
12	-	4140.248	Condenser	34	34	4140.234	Foot
-	12	4140.264	Condenser	35	35	S/R	Wheel Axle
13	13	4140.249	Fan Blade	37	37	4140.263	Inox Tank Support
14	14	4140.250	Motor	38	38	S/R	Back Panel
15	15	4140.251	Fan Bracket	39	39	S/R	Upper Base
16	16	4140.219	Wheel	40	40	S/R	Lower Base
17	-	4140.252	Compressor	41	41	S/R	Vertical Panel
-	17	4140.265	Compressor	42	42	S/R	Evaporator Support
18	-	4140.253	Compressor Starting Group	not shown	not shown	4140.257	Inside Cabling

DH 44 / DH 62




Fig. 2